



## easYgen-800/-1800 IDMT / Ground Fault formulas

Simon - 2021-12-15 - easYgen-800

### **Formulas for Overcurrent / Ground Fault**

- **IDMT Multiply of Overcurrent settings formula:**

$$T = t / ((IA/IT)-1)^2$$

**T** Overcurrent delay (seconds)

**t** Timing multiplier ratio

**IA** Current max. load current [L1/L2/L3]

**IT** Overcurrent setting value

Example

$$t = 36$$

$$IA = 550A$$

$$IT = 500A$$

Conclusion:  $T = 3600 s$

- **Delay Multiplier for Ground Fault formula:**

ground current delay action calculation (0.1s) = delay multiplier \* 0.14 / (((ground current / ground current threshold)<sup>0.02</sup> - 1)