



easYgen-800/-1800 IDMT / Ground Fault formulas

Simon - 2021-12-15 - easYgen-800

Formulas for Overcurrent / Ground Fault

- **IDMT Multiply of Overcurrent settings formula:**

$$T = t / ((IA/IT)-1)^2$$

T Overcurrent delay (seconds)

t Timing multiplier ratio

IA Current max. load current L1/L2/L3

IT Overcurrent setting value

Example

$$t = 36$$

$$IA = 550A$$

$$IT = 500A$$

$$\text{Conclusion: } T = 3600 \text{ s}$$

- **Delay Multiplier for Ground Fault formula:**

ground current delay action calculation (0.1s)=delay multiplier*0.14/(((ground current/ground current threshold)^{0.02})-1)