



[Knowledgebase](#) > [MFR300](#) > [I'm unable to change Toolkit Parameters in MFR300 relay \(kW transducer\)](#)

I'm unable to change Toolkit Parameters in MFR300 relay (kW transducer)

Clemens - 2025-09-04 - [MFR300](#)

Please use **Level 4 login credentials**:

[Toolkit Login Password Generator](#)

Enter the Random Number and it will generate the dynamic Level 4 password.

Alternately, you can use Code Level 5.

Beware that Level 5 login is permitted to change its own password, and if this is lost, it cannot be recovered except by Woodward.

Code is **0 5 0 0**