



Which Software and configuration cable is required for my control?

Clemens - 2024-10-10 - Software Tools

[Link to Software Downloads here](#)

| Product | Software Tool | required cable |
|---|------------------------------|---|
| AMG-4 GCP-10 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| AMG-3 GCP-20 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| AMG-2 GCP-30 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| MFR11, 12,13, 14,15 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| MFR2, 3 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| SPM-D | none | none |
| SPM-D2 | ToolKit | USB cable |
| ESDR-4 | none | none |
| GW4 | none | none |
| IKD1M | LeoPC1 or SW ID Changer Tool | DPC-1 5417-557 or DPC-USB 5417-1251 |
| easYlite-100 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| easYlite-200 | ToolKit-SC | USB |
| MFR300 (green housing) | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| MFR300 (black housing) | ToolKit | DPC-1 5417-557 or DPC-USB 5417-1251 |
| easYgen-300 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| easYgen-400 | ToolKit-SC | USB cable |
| easYgen-600 | ToolKit-SC | USB cable |
| easYgen-800 | ToolKit-SC | USB cable |
| easYgen-1400 | ToolKit-SC | USB cable |
| easYgen-1500 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| easYgen-1600 | ToolKit-SC | USB cable |
| easYgen-1700 | Toolkit-SC | USB cable |
| easYgen-1800 | ToolKit-SC | USB cable |
| easYgen-2200,2300,2500 | ToolKit | DPC-1 5417-557 or DPC-USB 5417-1251 |
| easYgen-3100/3200/3400/3500 first generation | ToolKit | RS232 Null modem cable * consider a USB to RS232 converter |
| easYgen-3100XT/3200XT/3400XT-P1/P2/3500XT-P1/P2 | ToolKit | USB (Type B), Ethernet |
| DSL-2 MSLC-2 | ToolKit | RS232 null modem cable, Ethernet |
| DSL-2XT MSLC-2XT | ToolKit | USB (Type B), Ethernet |
| RP-3000 | ToolKit | RS232 Null modem cable * consider a USB to RS232 converter |
| RP-3000XT | none | Ethernet |
| LS-4 | LeoPC | DPC-1 5417-557 or DPC-USB 5417-1251 |
| LS-5 | ToolKit | DPC-1 5417-557 or DPC-USB 5417-1251 |
| LS-6XT | ToolKit | USB (Type B), Ethernet |
| GC-3400XT | ToolKit | USB (Type B), Ethernet |
| DTSC-50 | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| DTSC-200 | ToolKit | DPC-1 5417-557 or DPC-USB 5417-1251 |
| DTSC-200A | ToolKit | USB |

Legacy Woodward Industrial Controls

| | | |
|--------|---|--|
| DSLC | | Handheld Programmer 9907-205 |
| MSLC | | Handheld Programmer 9907-205 |
| EGCP-1 | ServLink, Watch Window Pro | RS422/RS232 5417-551 ASSY RS422 |
| EGCP-2 | ServLink, Watch Window Pro | RS422/RS232 5417-551 ASSY RS422 FOR EGCP2 5417-551 |
| EGCP-3 | Watch Window, Watch Window Pro, Control Assistant | RS-232/ -422 / -485 |
| SPM-A | none | none |
| LSM | none | none |

Woodward Speed Controllers

| | | |
|---------------------------|--|--|
| SG-2D | LeoPC1 | DPC-1 5417-557 or DPC-USB 5417-1251 |
| EPG | none | none |
| DPG-2xxx | Universal PST | P/N 8447-1003 Adapter cable kit |
| APECS 2000 | none | none |
| APECS 3000 | APECS All Purpose Calibration Tool (ACT) | P/N SA-4455 Adapter cable kit |
| APECS 4000 | APECS All Purpose Calibration Tool (ACT) | P/N SA-4475 Adapter cable kit |
| APECS 4500 | APECS All Purpose Calibration Tool (ACT) | P/N SA-4488 ACT Kit |
| APECS 5000 | APECS All Purpose Calibration Tool (ACT) | P/N SA-4488 ACT Kit |
| L-series | L-series Service Tool | P/N 8923-1061 L-SERIES SERIAL COMMUNICATIONS INTERFACE |
| F-series 14 pin connector | ToolKit FST | P/N 8923-1254 F-SERIES COMMUNICATION HARDWARE, 14 PIN |
| F-series 23 pin connector | ToolKit FSTP | P/N 8923-1255 F-SERIES COMMUNICATION HARDWARE, 23 PIN |
| 2301A | none | none |
| 2301D | Servink, Watch Window | RS232 null modem cable |

2301E

ToolKit or Control Assistant

RS232 null
modem cable