

Knowledgebase > LS-5 > Can I operate LS-5 without current sensing?

Can I operate LS-5 without current sensing?

Clemens - 2022-03-30 - LS-5

Yes this is possible to install LS-5 without wiring the CT inputs.