



Knowledgebase > Engine > Idle Run / Idle Mode configuration options in easYgen-3000XT

Idle Run / Idle Mode configuration options in easYgen-3000XT

Özgür Tosun - 2024-11-26 - Engine

Idle Mode / Idle Run

- Short Description, with excerpts of our technical manual and ToolKit parameter screens example



Parameter descriptions



Configuration Screen in ToolKit



Example for a configuration of a hard-wired relay output, that signals the engine to switch to Idle run.

