



[Knowledgebase](#) > [easYgen-3000XT](#) > [Which CAN bus I use for easYgen-3000 loadsharing?](#)

## Which CAN bus I use for easYgen-3000 loadsharing?

Clemens - 2024-10-10 - [easYgen-3000XT](#)

- easYgen 3100/3200/3100XT/3200XT controls do load sharing via ethernet and/or CAN#1.
- easYgen 3400/3500/3400XT/3500XT controls do load sharing via redundant/single ethernet B/C or CAN#3.