



[ナレッジベース](#) > [Software Tools](#) > [Which Software and configuration cable is required for my control?](#)

# Which Software and configuration cable is required for my control?

Clemens - 2026-03-23 - [Software Tools](#)

[Link to Software Downloads here](#)

| Product   | Software Tool                                     | required cable                             |  |
|---|---|--|--|
| AMG-4 GCP-10                                    | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| AMG-3 GCP-20                                    | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| AMG-2 GCP-30                                    | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| MFR11, 12,13, 14,15                             | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| MFR2, 3   | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| SPM-D   | none  | none                                       |  |
| SPM-D2  | ToolKit   | USB cable                                  |  |
| ESDR-4  | none  | none                                       |  |
| GW4   | none  | none                                       |  |
| IKD1M   | LeoPC1 or SW ID Changer Tool                      | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| easYlite-100                                    | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| easYlite-200                                    | ToolKit-SC  | USB  |  |
| MFR300 (green housing)                          | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| MFR300 (black housing)                          | ToolKit   | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| easYgen-300                                     | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| easYgen-400                                     | ToolKit-SC  | USB cable                                  |  |
| easYgen-600                                     | ToolKit-SC  | USB cable                                  |  |
| easYgen-800                                     | ToolKit-SC  | USB cable                                  |  |
| easYgen-1400                                    | ToolKit-SC  | USB cable                                  |  |
| easYgen-1500                                    | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| easYgen-1600                                    | ToolKit-SC  | USB cable                                  |  |
| easYgen-1700                                    | ToolKit-SC  | USB cable                                  |  |
| easYgen-1800                                    | ToolKit-SC  | USB cable                                  |  |
| easYgen-2200,2300,2500                          | ToolKit   | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| easYgen-3100/3200/3400/3500 first generation    | ToolKit   | RS232 Null modem cable                     |  |
| easYgen-3100XT/3200XT/3400XT-P1/P2/3500XT-P1/P2 | ToolKit   | * consider a <b>USB to RS232 converter</b> |  |
| DSL-2 MSLC-2                                    | ToolKit   | USB (Type B), Ethernet                     |  |
| DSL-2XT MSLC-2XT                                | ToolKit   | RS232 null modem cable, Ethernet           |  |
| RP-3000   | ToolKit   | USB (Type B), Ethernet                     |  |
| RP-3000XT                                       | ToolKit   | RS232 Null modem cable                     |  |
| LS-4  | none  | * consider a <b>USB to RS232 converter</b> |  |
| LS-5  | LeoPC   | Ethernet                                   |  |
| LS-6XT  | LeoPC   | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| GC-3400XT                                       | ToolKit   | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| DTSC-50   | ToolKit   | USB (Type B), Ethernet                     |  |
| DTSC-200  | LeoPC1  | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
| DTSC-200A                                       | ToolKit   | DPC-1 5417-557 or DPC-USB 5417-1251        |  |
|   | ToolKit   | USB  |  |
| <b>Legacy Woodward Industrial Controls</b>      |   |  |  |
| DSL-2   |   |  | Handheld Programmer<br>9907-205                                |
| MSLC  |   |  | Handheld Programmer<br>9907-205                                |
| EGCP-1  | ServLink, Watch Window Pro                        |  | RS422/RS232<br>5417-551<br>ASSY RS422                          |
| EGCP-2  | ServLink, Watch Window Pro                        |  | RS422/RS232<br>5417-551<br>ASSY RS422<br>FOR EGCP2<br>5417-551 |
| EGCP-3  | Watch Window, Watch Window Pro, Control Assistant |  | RS-232/<br>-422 /<br>-485                                      |
| SPM-A   | none  |  | none   |
| LSM   | none  |  | none   |
| <b>Woodward Speed Controllers</b>               |   |  |  |
| SG-2D   | LeoPC1  |  | DPC-1 5417-557 or DPC-USB 5417-1251                            |
| EPG   | none  |  | none   |
| DPG-2xxx  | Universal PST                                     |  | P/N 8447-1003<br>Adapter cable kit                             |
| APECS 2000                                      | none  |  | none   |
| APECS 3000                                      | APECS All Purpose Calibration Tool (ACT)          |  | P/N SA-4455<br>Adapter cable kit                               |
| APECS 4000                                      | APECS All Purpose Calibration Tool (ACT)          |  | P/N SA-4475<br>Adapter cable kit                               |
| APECS 4500                                      | APECS All Purpose Calibration Tool (ACT)          |  | P/N SA-4488 ACT<br>Kit   |

|                           |  |  |
|---------------------------|--|--|
| APECS 5000                | APECS All Purpose Calibration Tool (ACT) | P/N SA-4488 ACT Kit                                    |
| L-series                  | L-series Service Tool                    | P/N 8923-1061 L-SERIES SERIAL COMMUNICATIONS INTERFACE |
| F-series 14 pin connector | ToolKit FST                              | P/N 8923-1254 F-SERIES COMMUNICATION HARDWARE, 14 PIN  |
| F-series 23 pin connector | ToolKit FSTP                             | P/N 8923-1255 F-SERIES COMMUNICATION HARDWARE, 23 PIN  |
| 2301A                     | none                                     | none   |
| 2301D                     | Servink, Watch Window                    | RS232 null modem cable                                 |
| 2301E                     | ToolKit or Control Assistant             | RS232 null modem cable                                 |